

InfoChip Bluetooth EasyReader - iPad/iPhone addendum

Problem: Due to Apple software design, the iPad/iPhone keyboard disappears when connected to a bluetooth keyboard, and there currently seems to be no way to stop this behaviour. The InfoChip Bluetooth EasyReader acts like a bluetooth keyboard.

Resolution: Set the Bluetooth Off Time to 0 in the Bluetooth EasyReader options. This disconnects the EasyReader from the iPad/iPhone immediately after a chip scan, which allows the iPad keyboard to re-appear. This also causes a slight delay when scanning the next chip, because the EasyReader must first re-connect to the iPad/iPhone.